AN 01-60G-4

FUSELAGE GROUP

FRONT FUSELAGE COMPLETE FRAME ASSEMBLY

Figure & Index Number	PART NUMBER	1 2 3 4 5 6 7 NOMENCLATURE	USAGE CODE	UNITS PER ASSY
	AN394-31	Pin—Flat head, 1/4	J	1
	AN394-33	Pin—Flat head, 1/4	H	2
	AN960-416	Washer—Plain	All	2
	AN960-416	Washer—Plain	H	2
13-24	82-735124	Pin—Fuselage station 70 armor plate door shock	All	2
13-25	98-735135	Plate—Fuselage station 70 to 132 left side armor	H	1
	108-735135	Plate—Fuselage station 70 to 132 left side armor	J	1
13-26	108-735235	Plate—Fuselage station 70 to 132 left side armor	J	1
13-27	98-310515	Hatch Assy—Fuselage pilot's escape (See figure 20)	All	Ref
13-28	62-310500-25	Hatch Assy—Fuselage bombardier's compartment escape (See figure 17)	J	Ref
13-29	62-310287	Cover Assy—Fuselage front entrance hatch (See figure 30)	All	Ref
13-30	98-310385	Door Assy—Fuselage front entrance hatch cannoneer's floor	H	1
	108-310385	Door Assy—Fuselage front entrance hatch turret gunner's floor	K-L	1
	108-310390	Door Assy—Fuselage front entrance hatch turret gunner's floor	M-S	1
13-31	8S1-78	Strap Assy—(Front entrance hatch)	B-C, K-L	1
	7S6-832-8	Screw—100 flat head	H	7
	AN365-832	Nut—Self locking	H	7
13-32	98-53207	Catch Assy—Front entrance hatch	C, L-S	1
13-33	AN393-39	Pin—Flat head, 3/16	C, L-S	1
13-34	98-53209	Bracket Assy—Front entrance hatch catch	C, L-S	1
13-35	2W1-13-20-63	Washer—Plain	C, L-S	3
13-36	98-53210	Catch—Front entrance inner hatch	C, L-S	1
13-37	98-53208	Spring—Front entrance hatch door catch	C, L-S	1
13-38	4S3-10-10	Spacer—Bolt	C, L-S	1
13-39	62-31005-4	Door Assy—Fuselage auxiliary landing gear complete (See figure 29)	A-B, K-L	Ref
	98-31005	Door Assy—Fuselage auxiliary landing gear complete (See figure 29)	C, M-S	Ref



Figure 14 FRONT FUSELAGE BOLTING DETAIL